




WALKMAN  
NW-WS413/WS414

4-580-536-12(1)


©2016 Sony Corporation Printed in Malaysia






# 1










# 2







# 3





Ⓜ "On"



**Windows**  
**Music Center for PC**  
<http://www.sony.net/smc4pc/>

**Mac**  
**Content Transfer for Mac**  
<http://www.sony.net/ct-mac/>

**i**

[http://rd1.sony.net/help/dmp/nwws410/h\\_ww/](http://rd1.sony.net/help/dmp/nwws410/h_ww/)