

English

For the owners of DCR-SR42A/ SR82C/SR200C/SR300C

Please use the chart below to determine which description in Operating Guide/Handycam Handbook applies to your camcorder model:

Note

- The model name is printed on the bottom of your Handycam product.

Model name

Model name of your Handycam	Model name used in Operating Guide/Handycam Handbook
DCR-SR42A	DCR-SR42
DCR-SR82C	DCR-SR82
DCR-SR200C	DCR-SR200
DCR-SR300C	DCR-SR300

EXCEPTIONS

Please disregard Operating Guide/Handycam Handbook with respect to information relating to your product's hard disk capacity, recording time, weight, actual performing time with [⊖EMPTY], and certain regulatory information.

Instead, please see the following:

Hard Disk capacity (p.35 on Operating Guide, p.50 on Handycam Handbook)

DCR-SR42A	60 GB
DCR-SR82C/ SR200C/SR300C	100 GB

Recording time (approx.) (p.16, 35 on Operating Guide, p.54 on Handycam Handbook)

DCR-SR42A	HQ	880 min.
	SP	1 300 min.
	LP	2 510 min.
DCR-SR82C/ SR200C/SR300C	HQ	1 440 min.
	SP	2 200 min.
	LP	4 210 min.

Weight (approx.) (p.37 on Operating Guide)

DCR-SR42A	345 g (12 oz) main unit only
	390 g (13 oz) including NP-FH40
	360 g (12 oz) main unit only
DCR-SR82C	405 g (14 oz) including NP-FH40
	465 g (1 lb) main unit only
	545 g (1 lb 3 oz) including NP-FH60
DCR-SR200C	490 g (1 lb 1oz) main unit only
	570 g (1 lb 4oz) including NP-FH60
	490 g (1 lb 1oz) main unit only
DCR-SR300C	570 g (1 lb 4oz) including NP-FH60
	570 g (1 lb 4oz) including NP-FH60
	570 g (1 lb 4oz) including NP-FH60

The actual performing time for [⊖EMPTY] (approx.) (p.51 on Handycam Handbook)

DCR-SR42A	60 min.
DCR-SR82C/ SR200C/SR300C	100 min.



3 210 467 110

3-210-467-11(1)

For customers in the U.S.A.

If you have any questions about this product, you may call:

Sony Customer Information Center 1-800-222-SONY (7669).

The number below is for the FCC related matters only.

Regulatory Information

Declaration of Conformity

Trade Name: SONY

Model No.: DCR-SR42A

Responsible Party: Sony Electronics Inc.
Address: 16530 Via Esprillo, San Diego,
CA 92127 U.S.A

Telephone number: 858-942-2230

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Declaration of Conformity

Trade Name: SONY

Model No.: DCR-SR82C

Responsible Party: Sony Electronics Inc.
Address: 16530 Via Esprillo, San Diego,
CA 92127 U.S.A

Telephone number: 858-942-2230

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Declaration of Conformity

Trade Name: SONY

Model No.: DCR-SR200C

Responsible Party: Sony Electronics Inc.
Address: 16530 Via Esprillo, San Diego,
CA 92127 U.S.A

Telephone number: 858-942-2230

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Declaration of Conformity

Trade Name: SONY

Model No.: DCR-SR300C

Responsible Party: Sony Electronics Inc.
Address: 16530 Via Esprillo, San Diego,
CA 92127 U.S.A

Telephone number: 858-942-2230

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Other than the information listed above, safety instructions and the FCC Regulation Rules are stated within the supplied Operating Guide/Handycam Handbook. Read these instructions thoroughly before operating your camcorder.

Español

Para los propietarios de los modelos DCR-SR42A/SR82C/SR200C/SR300C

Utilice la tabla siguiente para determinar qué descripción de la Guía de operaciones/Guía práctica de Handycam hace referencia a su modelo de videocámara:

Nota

- El nombre del modelo está impreso en la parte inferior del producto Handycam.

Nombre del modelo

Nombre de su modelo de Handycam	Nombre del modelo que se utiliza en la Guía de operaciones y en la Guía práctica de Handycam
DCR-SR42A	DCR-SR42
DCR-SR82C	DCR-SR82
DCR-SR200C	DCR-SR200
DCR-SR300C	DCR-SR300

EXCEPCIONES

No utilice la Guía de operaciones ni la Guía práctica de Handycam para consultar información acerca de la capacidad del disco duro, el tiempo de grabación, el peso, el tiempo real de ejecución de la función [OVACIAR] y cierta información reguladora relacionada con el producto. De lo contrario, vea lo siguiente:

Capacidad del disco duro (pág. 35 de la Guía de operaciones, pág. 55 de la Guía práctica de Handycam)

DCR-SR42A	60 GB
DCR-SR82C/ SR200C/SR300C	100 GB

Tiempo de grabación (aprox.) (pág. 14, 35 de la Guía de operaciones, pág. 59 de la Guía práctica de Handycam)

DCR-SR42A	HQ	880 min
	SP	1 300 min
	LP	2 510 min
DCR-SR82C/ SR200C/SR300C	HQ	1 440 min
	SP	2 200 min
	LP	4 210 min

Peso (aprox.) (pág. 37 de la Guía de operaciones)

DCR-SR42A	345 g unidad principal solamente 390 g con la batería recargable NP-FH40
DCR-SR82C	360 g unidad principal solamente 405 g con la batería recargable NP-FH40
DCR-SR200C	465 g unidad principal solamente 545 g con la batería recargable NP-FH60
DCR-SR300C	490 g unidad principal solamente 570 g con la batería recargable NP-FH60

Tiempo real de ejecución de la función [OVACIAR] (aprox.) (p.56 de la Guía práctica de Handycam)

DCR-SR42A	60 min
DCR-SR82C/ SR200C/SR300C	100 min